



B&W Trailer Hitches

1216 HWY 224 / PO Box 186

Humboldt, KS 66748

P:620.473.3664

F:620.473.3766

Relocation bracket installation instructions.

Refer to this guide when you have reached **STEP 6** in the instruction sheet.

INSTALLATION INSTRUCTIONS:

On certain models of the Diesel Ford Super Duty a sensor is located over a hole needed to install the passenger side plate of the B&W hitch. A relocation bracket has been supplied to displace the sensor so the side plate can be installed. To begin locate the sensor on the inside of the passenger frame rail. Once located, remove the two bolts holding the sensor to the frame. Next, place the supplied 3/4" bolt through the bracket as shown in figure 1.1. Next, place the sensor onto the bracket and replace the two bolts, see figure 1.2. Next, place the bolt through the oval hole in the frame and through the hole in the side plate with the bracket and sensor attached, See figure 1.3 and 1.4.

