



TRAILER HITCHES

Turnoverball® Gooseneck Hitch Fit List

	GNRK	GMRM	GNRC	PICKUP TRUCK YEAR, MAKE AND MODEL
CHEVROLET GMC	1016	1016	912	2016-2018 Chevrolet & GMC 2500 & 3500 Heavy Duty Trucks
	1012	1012	912	2011-2015 Chevrolet & GMC 2500 & 3500 Heavy Duty Trucks
	1057	1057	959	2007-2018 Chevrolet & GMC 1500 Short Bed Trucks with Boxed Frame
	1007	1007	959	2007-2018 Chevrolet & GMC 1500 Long Bed Trucks with Boxed Frame
	1067	1067	959	2001-2010 Chevrolet & GMC 2500 Heavy Duty Trucks 2007-2010 Chevrolet & GMC 3500 Trucks (With 1 bed cross member over the axle)
	1062	1062	962	2001-2007 Chevrolet & GMC 3500 Trucks (With 2 bed cross members over the axle)
	1059	1059	959	1999-2007 Chevrolet & GMC 1500 & 2500 Light Duty Trucks (Tube Frame changing to C-Channel before axle)
	1050	1050	950	1988-1998 Chevrolet & GMC 1500, 2500 & 3500 Short Bed Trucks 1999-2000 Chevrolet & GMC 2500 & 3500 Short Bed Trucks (Full C-Channel Frame)
	1000	1000	800	1988-1998 Chevrolet & GMC 1500, 2500 & 3500 Long Bed Trucks 1999-2000 Chevrolet & GMC 2500 & 3500 Long Bed Trucks (Full C-Channel Frame)
	1400	1400		1973-1987 Chevrolet & GMC 1500, 2500, & 3500 Trucks (Requires Drilling)
FORD	1117	1117	817	2017 Ford F250 & F350 4-Wheel Drive Super Duty Trucks 2017 Ford F450 4-Wheel Drive with factory installed bed
	1116	1117	816	2017 Ford F250 & F350 2-Wheel Drive Super Duty Trucks
	1111	1111	800	2011-2016 Ford F250 & F350 Super Duty Trucks 2011-2016 F450 with factory installed bed
	1115	1115	900	2015-2018 Ford F150 Gas Engine Trucks
	1104	1104	959	2004-2014 Ford F150 Trucks
	1108	1108	800	1999-2010 Ford F250 & F350 Trucks 2008-2010 F450 with factory installed bed
	1197	1197	800	1997-2003 Ford F150 & Light Duty F250 Trucks, & 2004 Heritage Edition
	1100	1100	800	1980-1998 Ford F250 & F350 Without Overload Springs
	1110	1110	800	1980-1998 Ford F250 & F350 With Overload Springs (Requires Drilling 2 Holes)
	1150	1150	800	1980-1996 Ford F150 Trucks
DODGE RAM	1314			2013-2017 Ram 3500 Trucks
	1384			2014-2017 Ram 2500 Trucks
	1309	1309	909	2009-2017 Dodge/Ram 1500 Trucks *Only GNXA4685 and RVK3500 with special post work with this hitch
	1313	1313	900	2013 Ram 2500 Diesel Trucks 2010-2012 Ram 2500 & 3500 Diesel Trucks 2003-2009 Dodge 2500 & 3500 Gas or Diesel Trucks
	1308	1308	907	2013 Ram 2500 Gas Engine Trucks 2013 Ram 2500 Mega-Cab Trucks 2010-2012 Ram 2500 & 3500 Gas Engine Trucks 2006-2012 Dodge/Ram 1500, 2500, & 3500 Mega-Cab Trucks
	1316	1316	900	2002-2008 Dodge 1500 Trucks (Except Mega-Cab)
	1394	1394	900	1994-2002 Dodge 2500 & 3500 Trucks 1994-2001 Dodge 1500 Trucks
	1300	1300		1973-1993 Dodge 1500, 2500, & 3500 Trucks (Requires Drilling)
	1257	1257	1256	2007-2017 Toyota Tundra All Beds *Only GNXA4585 and RVK3500 with special post work with this hitch
	1251	1251	1250	2000-2006 Toyota Tundra All Beds
OTHER	1208	1208	1218	2004-2017 Nissan Titan All Beds - Does Not Include Titan XD Trucks
	1500			Flatbed Kit 6"x8" - 1/2" Plate - 1/8" Socket Top Stick Out